



- NOTES**
1. Wires are not to be broken.
  2. Wires are to be covered with tape.
  3. See check chart for details.
  4. Wires are to be covered with tape.
  5. Tighten all nuts and bolts.
  6. Check for proper operation.
  7. Check for proper operation.

**NOTES**

1 -> INDICATES MALE CONNECTION.  
 2 -> INDICATES FEMALE CONNECTION.

**THE ENGINEER'S LATEST**  
**INTENSIVE SERVICE**  
**FOR ALL TYPES OF**  
**INDUSTRIAL**  
**ELECTRICAL**  
**EQUIPMENT**

**ELECTREX, INC.**  
 1000 W. 10TH ST.  
 DENVER, CO. 80202

**CUSTOMER:** J.M. ANDERSON  
**ORDER P/N:** 1000-1000  
**DATE:** 10/1/70

**REVISED BY:** J.M. ANDERSON  
**DATE:** 10/1/70